



Dimensiones Dimensions	mm	135 x70 x 30
---------------------------	----	--------------

1. Fijación mural Wall fixing Fixation au mur



- A** pegar percha en la pared
fix hanger on the wall
fixe le support mural




- B** taladrar y atornillar (opcional)
drill and screw (optional)
perforer et visser (optionnel)




- C** colocar el amplificador
place amplifieur
accrocher l'amplificateur



2. Conexión red alterna Connecting to the mains supply Raccordement secteur




3. Apertura de la caja Opening the housing Ouverture du boîtier



4. Modelos Models Modèles

- ATP290 serie: 2 Salidas/Outputs/Sorties Terr+Sat+VR



47-694 MHz

5. Ejemplo de instalación Installation example Exemple d'installation

